



## AC10-How to setup parental control

Function Config | Last updated: 2018/5/31

Model Number: Tenda AC10  
Question Classification: Function Setting

Step 1: Open a browser and type [tendawifi.com](http://tendawifi.com) in Address Bar, tap "Enter", Input login password and tap "Login"




Step 2: Tap "VPN" tap the  to choose the device you want to manage.




Step 3: Finish the settings, tap "Save"



① Devices name: tap  to change device name for easy distinguishing. Tap "Save" to save the device name.



② Internet Accessible: set up when you allow it to access the internet.



③ Website Access Limit: blacklist specifies what websites are unavailable. Whitelist specifies what websites are available.



Step 4: If you want to release Parental Control on specified device, Please tap 



Step 5: If you want to set up Parental Control for this device again, tap 



Download 

Document category: Function Config

Related products: AC10